



1. fold and glue together the seat pillows part





2. glue together the two parts of the ejection seat shell



## Q-5J two-seater cockpit instructions

Part designations use **blue numbers** so they are not mixed up with parts of the aircraft model


3. glue the pillows part into the shell, glue the two bars that stand out together, with one facing inward, the other outward



4. glue together the headrest




5. add side rests and face curtain




the face curtain can also be glued on backwards, for aircraft that are on the ground




6. glue headrest on the seat, add the pillow and side fin



7. glue on seat belts  
repeat for second seat




## 8. assembly of front cockpit




**Beware** that parts with different numbers are not interchangeable, even if they look similar!

## 9. assembly of rear cockpit




## 10. build the HUD box

fold upper part like this



You may replace part **y** with a transparent part of the same shape & size

## 11. install both cockpits.



## 12. install seats, HUD and screen

