


Part designations use lowercase letters so they are not mixed up with parts of the aircraft model.

Sea Hawk cockpit

instructions


1. Glue together the shell of the ejection seat.




2. Glue the sides on the two feet of the seat. for the middle part, the printed side should face inwards.




3. Glue the feet and the back on the shell.




4. Glue in the pillows/floats (optional).




5. Build the headrest, glue on the main seat belts.




6. Glue the headrest on the seat, glue on the lapbelts.




6. Glue the side panel extension on the port side panel.




7. Build the cockpit tub, glue in the main panel, joystick, side panels and pedals.



8. Glue the cockpit into the forward fuselage.




9. Glue in the ejection seat and the hood of the panel.



Sea Hawk with Ekco radar pod only

10. Glue the radar viewport on top of the hood.



All other Sea Hawks

10. Glue the gun aim on the hood.

